

make charging easy

Viel Fahrspass und
einfaches Laden!

Have fun driving
and easy loading!

frunk.GmbH
Krispl 19
A-5425 Krispl
Tel : 0043-676/7551234
e-mail: info@frunk.at



make charging easy

Einbauanleitung *frunk*
Installation instructions *frunk*

BMW iX3



①

Installation instructions *frunk*

1. Pull engine cover with a jerk.



pic 1

2. Remove the two rubber buffers from the engine cover.



pic 2

3. Press both rubber buffers from down into the openings of the *frunk* until they click into place.



pic 3

Einbauanleitung *frunk*

1. Motorabdeckung mit Ruck abziehen.

2. Zwei Gummipuffer von der Motorabdeckung entnehmen.

3. Beide Gummipuffer von der Unterseite in die Ausnehmungen des *frunk* drücken, bis diese einrasten.



(2)

4. Mount the stainless steel bracket:
- Insert the screws with the large washers from inside out.
 - Put on the bracket, fix it with the small washers and the nuts.
 - Screw on only hand-tight for the time being.



pic 4+5

5. Use **frunk**:
- push rubber buffers „**B**“ and „**C**“ onto existing ball pins.



pic 6

6. Insert the screw clamp „**A**“ through the existing opening and screw tight.



pic 7+8



(3)

7. Fix attachment point „**D**“:
Attach the screw clamp to the right-hand tube and screw it to the stainless steel bracket.



pic 9+10

8. Position the stainless steel bracket in height and screw tight.

9. Check that it is firmly seated.

Done!



pic 11

Note:

- Do not load over the top edge of the **frunk**.
- Remove before visiting the workshop.
- Maximum load 12 kg

4. Edelstahl Winkel montieren:
- Die Schrauben mit den großen Unterlegscheiben von innen nach außen einsetzen.
 - Den Winkel aufsetzen, mit den kleinen Unterlegscheiben und den Muttern fixieren, vorerst handfest anschrauben.

5. **frunk** einsetzen:
- Gummipuffer „**B**“ und „**C**“ auf die Kugelbolzen aufstecken.

6. Schraubschelle „**A**“ einbauen und anschrauben.

7. Befestigungspunkt „**D**“ fixieren:
Die Schraubschelle am Rohr anbringen und mit dem Edelstahl Winkel festschrauben.

8. Den Edelstahl Winkel in der Höhe positionieren und festschrauben.

9. Festen Sitz kontrollieren - fertig!

Hinweis:

- Nicht über die **frunk** - Oberkante beladen.
- Vor Werkstattbesuch entnehmen.
- Maximale Beladung 12 kg.

