

make charging easy

Viel Fahrspass und
einfaches Laden!



Einbauvideo / Installation video

frunk.GmbH
Krispl 19
A-5425 Krispl
Tel : 0043-676/7551234
e-mail: info@frunk.at



make charging easy

Einbauanleitung *frunk* Installation instructions *frunk*

BMW iX1



Installation instructions *frunk*

The *frunk* is attached to the existing spacer bolts using four vibration dampers.

1. Pull off the motor cover with a jerk. pic 1



pic 1

2. Install *frunk*:

- Position the vibration dampers (A, B, C and D) mounted on the *frunk* on the existing spacer bolts. pic 2
- By pressing on the attachment point (A, B, C and D,) in alphabetical order, the *frunk* is fixed on the spacer bolts. pic 3
- Make sure that all four vibration dampers snap into place on their respective spacer bolts.



pic 2

3. Check:
Check for a tight fit - done!



pic 3

Notes:

- Do not load above the top edge of the *frunk*.
- Remove before visiting the workshop.
- Maximum load 10kg.
- QR code for installation video on the back.

Einbauanleitung *frunk*

Der *frunk* wird durch vier Vibrationsdämpfer an den bestehenden Abstandsbolzen (A, B, C und D) befestigt.

1. Motorabdeckung mit kurzem Ruck abziehen pic 1

2. *frunk* aufsetzen:

- Die am *frunk* montierten Vibrationsdämpfer (A, B, C und D) auf die bestehenden Abstandsbolzen positionieren. pic 2
- Durch Druck auf die Befestigungspunkte (A, B, C und D) in alphabetischer Reihenfolge, wird der *frunk* fixiert. pic 3
- Achte darauf, daß alle vier Vibrationsdämpfer an den jeweiligen Abstandsbolzen einrasten.

3. Kontrolle:
Auf festen Sitz prüfen - fertig!

Hinweise:

- Nicht über die *frunk* - Oberkante beladen.
- Vor Besuch in der Werkstatt entnehmen.
- Maximale Beladung 10kg.
- QR-Code für Einbauvideo auf der Rückseite.